

PRODUCT SUPPORT TECHNICAL BULLETIN

October 26, 2023

Issue: Mounting The i16 to The Old-Style Stand

Cause:

The mounting holes on the old-style stand do not line up correctly with the bottom of the i16.

Solution:

Securely mount the i16 to the stand with our retrofit brackets.

Process: Approx 5-minute repair.

First determine if you have an old style stand, or new style stand by looking at the label on the box:

	Old Style
	New Style

Holes in the bracket lining up with screws in the i16 and stand. Attaching the bracket to the back of the i16 should look like this:

	Reuse Screws in the i16 and Stand