

S18 Countertop Flow Meter Instructions Setting Capacity & Timing

Setting Capacity & Timing

Keep pressing **DISPLAY** button

Then press **RESET** button and
release both of the buttons.

The DigiFlow 8000T will go into
setting procedure.

The digit will flash to notice you that
the setting procedure is on.

Setting Capacity

Press **DISPLAY** button to choose
the capacity.

The sequence is:
0-100-200-300.....9800-9900-OFF-
0-100.

Then press **RESET** button to save
the capacity.

Then go into Timing setting.

*The capacity mode will be disabled
when you choose OFF.

